FLASH PATTERN

- Random (default)
- Single (split)
- Double (split)
- Quad (split)
- Quint (split)
- Mega (split)
- 6 Ultra (split)
- Single-Quad (split)
- 8 Single H/L (split)
- Single (all)
- 10 Double (all)
- 11 Quad (all)
- 12 Quint (all)
- 13 Mega (all)
- 14 Ultra (all)
- 15 Single-Quad (all)
- 16 Single H/L (all)
- 17 Steady 2 (california)
- 18 Steady 4 (all)

Momentarily apply +VDC to YELLOW wire:

- · once for next pattern
- · quickly three times for reset

Note: This unit is not factory set at pattern 0



RED

AMBER

BLUE

GREEN

WHITE

RED

12 VDC

24 VDC

FLANGE COLOR

BLACK

CHROME

To +VDC (fuse @ 3A)

To Chassis Ground

For Simultaneous or Alternating Flash WHITE

Group1 Heads: (Wiring- WHITE connected to RED) will flash together Group2 Heads: (Wiring- WHITE not connected to RED) will flash together

Group1 Heads will alternate with Group2 Heads

Connect YELLOW wires of all heads together for synchronization

*All heads must be set at the same pattern

